



1. Remove OE plastic dust guard.
2. Disassemble the skid plate to component parts.
3. Fix the skid plate's beam to the radiator's beam with bolts M 8x20 -(A).
4. Fix skid plate's lugs to the front axle beam's steel element.
5. Fix the skid plate to mounted elements with bolts M 8x20 - (B),(C).
6. Tighten all screw joints.

