

Mitsubishi Colt

Year:2004-;

V: 1.3; 1.6;

VIN:- XMCXNZ36A5F02464

TYPE :14.652

1. Remove the standard dust-coat.
2. Fix the corbels and fasten them to the longerons with straps (A).
3. Fix the straps SD17001 to the apertures on the front axle beam.
4. Put the skid plate under the bumper and fasten it to the already mounted corbels with M 10x20 bolts (C).
5. Fasten the rear part to the front axle beam with straps (B).
6. Additionally fix the standard bolts in their original positions.
7. Tighten all screw joints.

