

INSTALLATION MANUAL: 1 Disassemble the skid plate to component parts.

2 Fix corbels "1" to the vehicle's towing lugs

3 Mount threaded inserts with bolts "2" into the front axle beam's apertures. 4 Install the rear part of the skid plate on the mounted bolts

5 Fix the front part of the skid plate to the mounted corbels 6 Tighten all screw joints.

OPERATING CONDITIONS:

Engine bay and transmission elements skid plate has been designed to operate in conditions specified by vehicle's producer. Cases of crush or driving into obstacles, at a speed should be excluded during exploitation. In case of head-on crush it is necessary to assure in absence of damages of vehicle's components and units and availability of roadworthiness on certified service stations

WARRANTY:

Warranty period - 1 year

WARRANTY TERMS:

The skid plate should be installed on a vehicle with undamaged body and load-bearing elements (vehicle, which hads never been involved in road traffic accident);

There are no mechanical damages of the skid plate resulting from head-on crush. All requirements to skid plate installation should be satisfied: There are no mechanical damages of powder coating.

Producer does not bear liability for damages caused to the vehicle, health and life of people in case of installation and exploitation terms violation. Producer has a right to introduce changes into the skid plate construction.



The Quality Management System of LLC Metalloproduktsia has been audited by Bureau Veritas Certification and conforms to requirements of the ISO 9001:2008 standard.





NO.	NAME	QTY.	NO.	NAME	QTY.
1	Corbels	2	5	Bolt M 10x30	6
2	Threaded insert	2	6		
3	Washer 10	6	7		
4	Special washer	2	8		

Thread	M6x1.0	M8x1.25	M10x1.5	M12x1.7
Fightening torque	9.8 Нм	24.0 HM	47.0 HM	81.0 HM