

- 1. Disassemble the skid plate to component parts. Insert threaded inserts "2" into longerons apertures.
- 3. Fix lateral skid plate's wings for mounted threaded inserts. Front part of each wing should be fixed with QE bolt.
- 4. Insert threaded inserts "2" into the front axle beam apertures and screw bolts M10x30 in them.
- Fix the skid plate to mounted threaded inserts and lateral wings. 6. Tighten all screw joints.

OPERATING CONDITIONS:

Engine bay and transmission elements skid plate has been designed to operate in conditions specified by vehicle's producer. Cases of crush or driving into obstacles, at a speed should be excluded during exploitation. In case of head-on crush it is necessary to assure in absence of damages of vehicle's components and units and availability of roadworthiness on certified service stations.

WARRANTY:

Warranty period - 1 year.


WARRANTY TERMS:

The skid plate should be installed on a vehicle with undamaged body and load-bearing elements (vehicle, which hads never been involved in road traffic accident): There are no mechanical damages of the skid plate resulting from head-on crush. All requirements to skid plate

installation should be satisfied: There are no mechanical damages of powder coating.

Producer does not bear liability for damages caused to the vehicle, health and life of people in case of installation and exploitation terms violation. Producer has a right to introduce changes into the skid plate construction.

The Quality Management System of LLC Metalloproduktsia has been audited by Bureau Veritas Certification and conforms to requirements of the ISO 9001:2008 standard.



LIST OF PARTS				
NO.	NAME	QTY.		
1	Wing	2		
2	Threaded insert	4		
3	Bolt M8x20	6		
4	Bolt M10x30	4		
5	Washer 8	6		
6	Washer 10	4		

Thread	M6x1.0	M8x1.25	M10x1.5	M12x1.75
Tightening torque	9.8 Nm	24.0 Nm	47.0 Nm	81.0 Nm