

- INSTALLATION MANUAL: Disassemble the skid plate to component parts.
- 2. Fix straps to apertures in longerons.
- 3. Fix corbel x 1 a turning it in the way shown on the scheme. 4. Fix corbel «2» turning it in the way shown on the scheme.
- 5. Fix straps threaded inserts into the front axle beam apertures. 6.Fix the front part of the skid plate to installed corbels with bolts M 10x20; fix the rear part of the skid plate to mounted straps with bolts M 10x30.

## 7 Tighten all screwigints OPERATING CONDITIONS:

Engine bay and transmission elements skid plate has been designed to operate in conditions specified by vehicle's producer. Cases of crush or driving into obstacles at a speed should be excluded during exploitation. In case of head-on crush it is necessary to assure in absence of damages of vehicle's components and units and availability of roadworthingee on cartified equica etations

## WARRANTY:


## Warranty period - 1 year.

- WARRANTY TERMS: The skid plate should be installed on a vehicle with undamaged body and load-bearing elements (vehicle, which hads
- never been involved in road traffic accident): There are no mechanical damages of the skid plate resulting from head-on crush. All requirements to skid plate installation should be satisfied:
- There are no mechanical damages of powder coating. Producer does not bear liability for damages caused to the vehicle, health and life of people in case of installation and

exploitation terms violation. Producer has a right to introduce changes into the skid plate construction.



The Quality Management System of LLC Metalloproduktsia has been audited by Bureau Veritas Certification and conforms to requirements of the ISO 9001:2008 standard.



1	2	3	4	5	6-7	8
1	1	9	N.S.	0	Q	9

NO.	NAME	QTY.	NO.	NAME	QTY.
1	Corbel left	1	5	Washer 10	8
2	Corbel right	1	6	Bolt M 10x20	2
3	Threaded insert with boilt	2	7	Bolt M 10x30	4
4	Threaded insert	4	8	Nut M10	2

M0v1 26

M12x1.75