

INSTALLATION MANUAL:

- 1. Remove OE plastic duster. 2. Mount threaded inserts with bolts into girders' apertures .
- 3. Fix the skid plate's brackets to the mounted inserts.
- 4. Fix the skid plate's beam to the mounted brackets.
- 5. Install threaded inserts into the front axle beam and screw the bolts into them Install the rear part of the skid plate on the mounted bolts and fix it to the mounted beam.

7. Tighten all screw joints.

OPERATING CONDITIONS: Engine bay and transmission elements skid plate has been designed to operate in conditions specified by vehicle's producer. Cases of crush or driving into obstacles, at a speed should be excluded during exploitation. In case of head-on crush it is necessary to assure in absence of damages of vehicle's components and units and availability of madworthings on certified service stations

WARRANTY:

Warranty period - 1 year.

WARRANTY TERMS:


The skid plate should be installed on a vehicle with undamaged body and load-bearing elements (vehicle, which hads never been involved in road traffic accident): There are no mechanical damages of the skid plate resulting from head-on crush. All requirements to skid plate

installation should be satisfied: There are no mechanical damages of powder coating.

Producer does not bear liability for damages caused to the vehicle, health and life of people in case of installation and exploitation terms violation. Producer has a right to introduce changes into the skid plate construction.



The Quality Management System of LLC Metalloproduktsia has been audited by Bureau Veritas Certification and conforms to requirements of the ISO 9001:2008 standard.





LIST OF PARTS NAME QTY. NAME QTY. Threaded insert Bolt M 10x20 2 7 Threaded insert 2 Nut M10 Washer 8 Corbel left ø Corbel right Washer 10 Front axle beam

Thread	M6x1.0	M8x1.25	M10x1.5	M12x1.75
Tightening torque	9.8 HM	24.0 HM	47.0 HM	81.0 HM